

Rear Decklid Instructions

1. You will need 10/32" bolts, washers and nuts, decklid handle, and brackets.



2. Measure rear of Roadster above rear seat. (should be about 32in) Mark the center. Then measure about 12in from left and right from the center and mark. This should be where the brackets meet.



3. Install male bracket on car and female bracket on the decklid. Be sure to align brackets properly so that both sides fit in straight.



4. Measure 13 inches from the right wall along the black tape on the bottom seat area. Mark that point. From there you will need to cut a 3" x 1/4" hole to the left of that mark.



5. Measure bottom lip of decklid and mark center point. Measure about 1 3/4" above bottom lip of deck and mark. This is where to install decklid handle. Use 1" drillbit for centerpiece of the handle. Use 3/16" drillbit for screws of the handle. After installing decklid handle, make sure centerpiece does not hit the body when decklid is closed. If it hits body, shorten centerpiece accordingly.

